Three-position device JSHD4

JSHD4 is a three-position device used to allow a limited movement of the machine when the operator is in the dangerous area, for example during troubleshooting, test running and programming.

The operator pushes the larger black button to a middle position in order to allow a movement. In case of danger, the operator will either release the button or squeeze it to its bottom position and the machine will stop.

JSHD4 is available with different types of connectors for an optimal adaptation to the application. Some models offer additional top and front button to control a non-safe signal, for ex. move forward and/or backward.





Safety and protection

Cheat-safe hand recognition

All JSHD4 models comply with PLe/Cat 4. Some models offer an "anti-tamper" function: an extra signal indicate if the JSHD4 is held in the middle position by a human hand. A machine movement will be authorized only in presence of this signal and not if the device is held in run position by any other (fraudulent) mean.



Ergonomic shape and operation

JSHD4 is ergonomic, both in respect of its shape, fitting to the hand, and the way the buttons are operated. JSHD4 is easy to operate using just the fingers (even with gloves), and the middle position provides a safe resting position.



Safely inspect a running machine


JSHD4 allows the operators to safely inspect the manufacturing process without completely stopping the machine.

Applications and features JSHD4


Applications

Safe troubleshooting, programming and testing

If the operator has to enter a risk area for troubleshooting or test running, it is extremely important that he/she is able to stop the machinery without having to rely on someone else pushing a stop button. In addition, no-one else should be able to start the machinery after it has been stopped by the operator. An operator who is under pressure must also be able to give a stop signal, whether in panic he/she pushes harder on the button or just releases it.



JSHD4 three-position control device can be used for troubleshooting, programming and test running in situations where no other protection is available or feasible. JSHD4 allows the operator to safely inspect the process without completely stopping the machine. The big black button has 3 distinct positions: released, pressed gently and pressed hard. The middle position allows the machine to run with limited speed or range, but when released or pressed hard the machine stops.



Features

Hand recognition for protection against tampering

An optional "anti-tamper" function sends an extra signal to indicate if the JSHD4 is held by a human hand or not. By using this, the safety level is increased, and the risk of manipulation or bypass of the safety function is reduced. It is no longer possible to expose the operator to danger by trying to lock the three-position control device in run mode.

Ergonomic design

JSHD4 is ergonomic, both in respect of its shape, fitting to the hand and the way the buttons are operated. It is easy to operate the device by using just the fingers (even with gloves), and the middle position provides a secure resting position.

Additional top and front buttons for non-safe signals

The two additional buttons can be used for e.g. start/stop, up/down or forward/ back. Internally the device is duplicated. The three-position function itself is built up of two completely independent three-position buttons which feels as one button for the user.

Ordering information JSHD4







AB, AK - Cannon connection



AC, AD - M12 connection



AE - M12 with E-stop



AL - Cable gland and holder for Eva (used with JSM54)

Choose top part, bottom part and anti-tamper

| Top part | Bottom part | ., | | Anti- | : | |
|------------------------------------|---|-------|--------------------------------------|---------------------------------------|--------------|------------------------|
| Buttons and LEDs | Feature | ID | Connection | tamper | Туре | Order code |
| JSHD4-1 | Use your own cable | AA | Cable gland and 5 screw connections | | JSHD4-1-AA | 2TLA019995R0000 |
| No LEDs No buttons | Cost effective and quick connection | AC | M12-5 male | · · · | JSHD4-1-AC | 2TLA019995R010 |
| | Holder for Eva (used with JSM54) | AL | Cable gland and 10 screw connections | | JSHD4-1-AL | 2TLA019995R4700 |
| SHD4-2 | Cost effective and robust | AB | Cannon 12 male pins | ·· · | JSHD4-2-AB | 2TLA019995R0200 |
| LEDs Front button Top button | | | | Χ | JSHD4-2-AB-A | 2TLA019995R0300 |
| | Cost effective and quick connection | AD | M12-8 male | | JSHD4-2-AD | 2TLA019995R0400 |
| | | | | Χ | JSHD4-2-AD-A | 2TLA019995R050 |
| | Use your own cable, simplified | AH | Cable gland and 10 screw connections | | JSHD4-2-AH | 2TLA019995R080 |
| | connection | | | Χ | JSHD4-2-AH-A | 2TLA019995R090 |
| | Use your own cable, full pin | AJ | Cable gland and 16 screw | | JSHD4-2-AJ | 2TLA019995R100 |
| | connection | • | connections | Χ | JSHD4-2-AJ-A | 2TLA019995R110 |
| | Replacement of old units* | AK | Cannon 12 male pins | İ | JSHD4-2-AK | 2TLA019995R480 |
| | Holder for Eva (used with JSM54) | AL | Cable gland and 10 screw | - | JSHD4-2-AL | 2TLA019995R4900 |
| | | | connections | Х | JSHD4-2-AL-A | 2TLA019995R5000 |
| SHD4-3 | Cost effective and robust | AB | Cannon 12 male pins | : | JSHD4-3-AB | 2TLA019995R120 |
| EDs | | | | Х | JSHD4-3-AB-A | 2TLA019995R130 |
| o buttons | Cost effective and quick connection | AD | M12-8 male | | JSHD4-3-AD | 2TLA019995R140 |
| | | • | | Χ | JSHD4-3-AD-A | 2TLA019995R150 |
| | E-stop | ΑE | M12-8 male | | JSHD4-3-AE | 2TLA019995R160 |
| | Use your own cable, simplified | AH | Cable gland and 10 screw | | JSHD4-3-AH | 2TLA019995R200 |
| | connection | - | connections | Х | JSHD4-3-AH-A | 2TLA019995R210 |
| | Use your own cable, full pin connection | AJ | Cable gland and 16 screw connections | - | JSHD4-3-AJ | 2TLA019995R220 |
| | | | | Χ | JSHD4-3-AJ-A | 2TLA019995R230 |
| | Replacement of old units* | AK | Cannon 12 male pins | : | JSHD4-3-AK | 2TLA019995R510 |
| | Holder for Eva (used with JSM54) | AL | Cable gland and 10 screw | : | JSHD4-3-AL | 2TLA019995R520 |
| | | - | connections | Χ | JSHD4-3-AL-A | 2TLA019995R530 |
| SHD4-4 | Cost effective and robust | AB | Cannon 12 male pins | | JSHD4-4-AB | 2TLA019995R240 |
| EDs | | | | Χ | JSHD4-4-AB-A | 2TLA019995R250 |
| ront button | Cost effective and quick connection | AD | M12-8 male | . <u>;</u> | JSHD4-4-AD | 2TLA019995R260 |
| | | | | Χ | JSHD4-4-AD-A | 2TLA019995R270 |
| | Use your own cable, simplified | AH | Cable gland and 10 screw connections | | JSHD4-4-AH | 2TLA019995R300 |
| | connection | | | Χ | JSHD4-4-AH-A | 2TLA019995R310 |
| | Use your own cable, full pin | AJ | Cable gland and 16 screw connections | | JSHD4-4-AJ | 2TLA019995R320 |
| | connection | - | | X | JSHD4-4-AJ-A | 2TLA019995R330 |
| | Replacement of old units* | AK | Cannon 12 male pins | ÷ | JSHD4-4-AK | 2TLA019995R540 |
| | Holder for Eva (used with JSM54) | AL | Cable gland and 10 screw | : | JSHD4-4-AL | 2TLA019995R550 |
| | , | | connections | Χ | JSHD4-4-AL-A | 2TLA019995R560 |
| SHD4-5 | Cost effective and robust | AB | Cannon 12 male pins | · · | JSHD4-5-AB | 2TLA019995R340 |
| EDs . | | • | | X | JSHD4-5-AB-A | 2TLA019995R350 |
| op button | Cost effective and quick connection | AD | M12-8 male | · · · · · · · · · · · · · · · · · · · | JSHD4-5-AD | 2TLA019995R360 |
| | 4 | | | Х | JSHD4-5-AD-A | 2TLA019995R370 |
| | Use your own cable, simplified connection | AH | Cable gland and 10 screw | · · | JSHD4-5-AH | 2TLA019995R400 |
| | | | connections | X | JSHD4-5-AH-A | 2TLA019995R410 |
| | Use your own cable, full pin | AJ | Cable gland and 16 screw connections | <u>.</u> | JSHD4-5-AJ | 2TLA019995R420 |
| | connection | , | | X | JSHD4-5-AJ-A | 2TLA019995R430 |
| | Replacement of old units* | AK | Cannon 12 male pins | | JSHD4-5-AK | 2TLA019995R570 |
| | Holder for Eva (used with JSM54) | AL | Cable gland and 10 screw | <u>:</u> | JSHD4-5-AL | 2TLA019995R5800 |
| | , | . / - | connections | | 3311D1071L | : _12 10 100001 100001 |

 $^{^{\}star}$ See document $\underline{\text{2TLC010007L0201}}$ for information about replacement

Cables and connectors JSHD4



M12-C61



M12-C61HE



M12-C334



Cable with connectors

| Connector | Female/male | Length | Special feature | Туре | Order code |
|-----------|---------------|--------|---------------------------------|------------|-----------------|
| | Female | 6 m | | M12-C61 | 2TLA020056R0000 |
| | | | Harsh environment, halogen free | M12-C61HE | 2TLA020056R8000 |
| | | 10 m | | M12-C101 | 2TLA020056R1000 |
| | | | Harsh environment, halogen free | M12-C101HE | 2TLA020056R8100 |
| | | 20 m | | M12-C201 | 2TLA020056R1400 |
| | Female + male | 0.3 m | | M12-C0312 | 2TLA020056R5800 |
| | | 0.06 m | | M12-C00612 | 2TLA020056R6300 |
| | | 1 m | | M12-C112 | 2TLA020056R2000 |
| | | 3 m | | M12-C312 | 2TLA020056R2100 |
| | | 6 m | | M12-C612 | 2TLA020056R2200 |
| | | 10 m | | M12-C1012 | 2TLA020056R2300 |
| | | 16 m | | M12-C1612 | 2TLA020056R5400 |
| | | 20 m | | M12-C2012 | 2TLA020056R2400 |
| V112-8 | Female | 6 m | | M12-C63 | 2TLA020056R3000 |
| Ferr | | 10 m | | M12-C103 | 2TLA020056R4000 |
| | | 20 m | | M12-C203 | 2TLA020056R4100 |
| | Female + male | 0.06 m | | M12-C00634 | 2TLA020056R6400 |
| | | 1 m | | M12-C134 | 2TLA020056R5000 |
| | | 3 m | | M12-C334 | 2TLA020056R5100 |
| Cannon | Female | 5 m | | HK5 | 2TLA020003R4700 |
| | | 10 m | | HK10 | 2TLA020003R4800 |
| | | 20 m | | HK20 | 2TLA020003R4900 |
| | | 1.6 m | Spiral cable | HK16S4 | 2TLA020003R5000 |
| | | 3.2 m | Spiral cable | HK32S4 | 2TLA020003R5200 |
| | | 4 m | Spiral cable | HK40S4 | 2TLA020003R3500 |
| | | 6 m | Spiral cable | HK60S4 | 2TLA020003R3600 |
| | | 8 m | Spiral cable | HK80S4 | 2TLA020003R5300 |

Separate cables and connectors






| | 1020301 |
|----------|-----------------|
| C5 cable | 2TLC010038F0201 |

| Description | Туре | Order code |
|---|----------------|-----------------|
| Connectors | | |
| M12-5 pole female, straight | M12-C01 | 2TLA020055R1000 |
| M12-5 pole male, straight | M12-C02 | 2TLA020055R1100 |
| M12-8 pole female, straight | M12-C03 | 2TLA020055R1600 |
| M12-8 pole male, straight | M12-C04 | 2TLA020055R1700 |
| 12-pole female cannon connector for JSHD4 | JSHK0 | 2TLA020003R0300 |
| Cable with 5 conductors | | |
| 10 m cable with 5 x 0.34 shielded conductors | C5 cable 10 m | 2TLA020057R0001 |
| 50 m cable with 5 x 0.34 shielded conductors | C5 cable 50 m | 2TLA020057R0005 |
| 100 m cable with 5 x 0.34 shielded conductors | C5 cable 100 m | 2TLA020057R0010 |
| 200 m cable with 5 x 0.34 shielded conductors | C5 cable 200 m | 2TLA020057R0020 |
| 500 m cable with 5 x 0.34 shielded conductors | C5 cable 500 m | 2TLA020057R0050 |
| Cable with 8 conductors | | |
| 50 m cable with 8 x 0.34 shielded conductors | C8 cable 50 m | 2TLA020057R1005 |
| 100 m cable with 8 x 0.34 shielded conductors | C8 cable 100 m | 2TLA020057R1010 |
| 200 m cable with 8 x 0.34 shielded conductors | C8 cable 200 m | 2TLA020057R1020 |
| 500 m cable with 8 x 0.34 shielded conductors | C8 cable 500 m | 2TLA020057R1050 |


Accessories JSHD4




JSM 55 wall bracket and JSM 50H bracket for Eden

Accessories

| Description | Type | Order code |
|---|------------|-----------------|
| Brackets and bottom plates | | |
| JSM 55 Wall bracket for three position device | JSM 55 | 2TLA040005R0500 |
| JSM 5B Wall bracket for 2 pcs MKey5 interlock switches | JSM 5B | 2TLA040005R0700 |
| JSM 54A Wall bracket for Adam. Used with AL bottom part that has a holder for Eva | JSM 54A | 2TLA020205R2800 |
| JSM 50G Bracket for key switches | JSM 50G | 2TLA020205R6300 |
| JSM 50H Bracket for Eden sensor | JSM 50H | 2TLA020205R6400 |
| Others | | |
| JSHD4 protection coat | JSHD4 Coat | 2TLA020200R4600 |



JSM 50G bracket for key switches and JSM 5B wall bracket for 2 pcs MKey5




JSM 54A wall bracket for Adam (and AL bottom part that has a holder for Eva)



JSHD4 protection coat


Electrical wiring diagrams Examples with JSHD4-1 and JSHD4-2 models






JSHD4-1-AA, cable gland and 5 screw connections on JSHD4-1






JSHD4-2-AB-A, Cannon 12 pins





JSHD4-2-AK, Cannon 12 pins






JSHD4-2-AD-A, M12-8


Electrical wiring diagrams Examples with JSHD4-2 models






JSHD4-2-AH-A, cable gland and 10 screw connection





JSHD4-2-AL-A, cable gland and 10 screw connection





JSHD4-2-AJ-A, cable gland and 16 screw connection

Technical data and dimension drawings JSHD4


Technical data

| recillical data | | |
|--|---|--|
| Approvals | Inspecta 😡 🚯 | |
| Conformity | C € 2006/42/EC - Machinery EN ISO 12100:2010, EN 60204-1:2007+A1:2009, EN ISO 13849-1:2016 | |
| Functional safety data | | |
| EN ISO 13849-1:2016 | Up to PL e (depending on number of operations per year) B _{10d} · 2 000 000 to middle position, 968 000 to bottom position | |
| Electrical data | | |
| Current allowed, three-position button | Per channel: Maximum +30 VDC, 20 mA, (Minimum +10 VDC, 8 mA) | |
| Current allowed, extra button | Maximum 500 mA | |
| Operation force | Approx. 15 N for three-position buttons (ON) | |
| | Approx. 45 N for three-position buttons (OFF) | |
| | Approx. 2.5 N for top/front push button | |
| Mechanical data | | |
| Operating temperature | - 10+50 °C | |
| Protection class | IP65 | |
| Mechanical life | 1 000 000 cycles to middle position | |
| Weight | Approx. 0.2 kg without cable | |


More information

Fore more information, e.g. the complete technical information, see product manual for: JSHD4_2TLC172072M0201

Dimension drawings



JSHD4-2-AD



JSHD4-2-AL

All dimensions in mm

Contact us

ABB AB Jokab Safety

Varlabergsvägen 11 SE-434 39 Kungsbacka Tel. +46 (0) 21-32 50 00

You can find the address of your local sales organization on the ABB home page



www.abb.com



www.abb.com/jokabsafety

Note

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.

Copyright © 2017 ABB All rights reserved

